




HV600 Quick Setup Procedure for IP20/UL Type 1 Models HV60U2011 to 2114 and 4005 to 4124




Read and follow the safety and installation procedures in the Installation & Primary Operation (TOEPC71061732) manual packaged with the drive.


1 Confirm the Drive and Motor Specifications



2 Confirm the Correct Drive Installation Environment




3 Use the Enclosed Drilling Template to Mount the Drive Vertically



When you use non-metric hardware to install the drive, use Type B narrow washers or equivalent and make sure that the size of the screw head and washer are applicable for your drive before installation.

4 Select the Motor and Power Wires, Wire Strip Length, Crimp Terminals, and Branch Circuit Protection



208 V Class Wires and Crimp Terminals

Drive Model [HV60UXXXX]	Terminal	Wire Range AWG, kcmil (Recommended)	Panduit Crimp Terminal Part Number ^{1, 2}	Drive Model [HV60UXXXX]	Terminal	Wire Range AWG, kcmil (Recommended)	Panduit Crimp Terminal Part Number ^{1, 2}	Drive Model [HV60UXXXX]	Terminal	Wire Range AWG, kcmil (Recommended)	Panduit Crimp Terminal Part Number ^{1, 2}
2011	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 8 (14)	N/A	2031	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 8 (8)	N/A	2075	R/L1, S/L2, T/L3	8 - 2/0 (4)	LCA4-56-L
	-, +1	14 - 8 (14)	N/A		-, +1	14 - 8 (8)	N/A		U/T1, V/T2, W/T3	8 - 2/0 (3 or 2)	LCA4-56-L/LCA2-56-Q
	⊕	14 - 8 (12)	LCA10-14-L		⊕	14 - 8 (10)	LCA10-14-L		-, +1	8 - 2/0 (2)	LCA2-56-Q
2017	R/L1, S/L2, T/L3	14 - 8 (12)	N/A	2046	R/L1, S/L2, T/L3	14 - 4 (8)	N/A	2088	R/L1, S/L2, T/L3	8 - 2/0 (3 or 2)	LCA4-56-L/LCA2-56-Q
	U/T1, V/T2, W/T3	14 - 8 (10)	N/A		U/T1, V/T2, W/T3	14 - 4 (6)	N/A		U/T1, V/T2, W/T3	8 - 2/0 (2)	LCA2-56-Q
	-, +1	14 - 8 (10)	N/A		-, +1	14 - 4 (6)	N/A		-, +1	8 - 2/0 (1)	LCA1-56-E
2024	R/L1, S/L2, T/L3	14 - 8 (10)	N/A	2059	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 4 (4)	N/A	2114	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	8 - 2/0 (1/0)	LCA1/0-56-X
	U/T1, V/T2, W/T3	14 - 8 (8)	N/A		-, +1	14 - 4 (4)	N/A		-, +1	8 - 2/0 (2/0)	LCA2/0-56-X
	-, +1	14 - 8 (8)	N/A		⊕	14 - 4 (6)	LCA6-14-L		⊕	8 - 2/0 (6)	LCA6-56-L

480 V Class Wires and Crimp Terminals

Drive Model [HV60UXXXX]	Terminal	Wire Range AWG, kcmil (Recommended)	Panduit Crimp Terminal Part Number ^{1, 2}	Drive Model [HV60UXXXX]	Terminal	Wire Range AWG, kcmil (Recommended)	Panduit Crimp Terminal Part Number ^{1, 2}	Drive Model [HV60UXXXX]	Terminal	Wire Range AWG, kcmil (Recommended)	Panduit Crimp Terminal Part Number ^{1, 2}
4005 4008	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 8 (14)	N/A	4027	R/L1, S/L2, T/L3	14 - 8 (10)	N/A	4065	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 4 (4)	N/A
	-, +1	14 - 8 (14)	N/A		U/T1, V/T2, W/T3	14 - 8 (8)	N/A		-, +1	14 - 4 (4)	N/A
	⊕	14 - 8 (14)	LCA10-14-L		⊕	14 - 8 (10)	LCA10-14-L		⊕	14 - 4 (6)	LCA6-14-L
4011	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 8 (14)	N/A	4034	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 8 (8)	N/A	4077	R/L1, S/L2, T/L3	8 - 2/0 (4)	LCA4-56-L
	-, +1	14 - 8 (14)	N/A		-, +1	14 - 8 (8)	N/A		U/T1, V/T2, W/T3	8 - 2/0 (3 or 2)	LCA4-56-L/LCA2-56-Q
	⊕	14 - 8 (12)	LCA10-14-L		⊕	14 - 8 (10)	LCA10-14-L		-, +1	8 - 2/0 (2)	LCA2-56-Q
4014	R/L1, S/L2, T/L3	14 - 8 (14)	N/A	4040	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 8 (10)	N/A	4096	R/L1, S/L2, T/L3	8 - 2/0 (2)	LCA2-56-Q
	U/T1, V/T2, W/T3	14 - 8 (12)	N/A		-, +1	14 - 4 (6)	N/A		U/T1, V/T2, W/T3	8 - 2/0 (1)	LCA1-56-E
	-, +1	14 - 8 (10)	LCA10-14-L		⊕	14 - 4 (8)	LCA8-14-L		-, +1	8 - 2/0 (1)	LCA1-56-E
4021	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 8 (10)	N/A	4052	R/L1, S/L2, T/L3 U/T1, V/T2, W/T3	14 - 4 (6)	N/A	4124	R/L1, S/L2, T/L3	8 - 2/0 (1/0)	LCA1/0-56-X
	-, +1	14 - 8 (10)	N/A		-, +1	14 - 4 (4)	N/A		U/T1, V/T2, W/T3	8 - 2/0 (2/0)	LCA2/0-56-X
	⊕	14 - 8 (10)	LCA10-14-L		⊕	14 - 4 (8)	LCA8-14-L		-, +1	8 - 2/0 (2/0)	LCA2/0-56-X

¹ For use with PANDUIT Corp. heat-shrinkable tubing HSTT series or an equivalent UL-recognized-heat shrinkable tubing rated 600 V minimum.
² Refer to the Installation & Primary Operation (TOEPC71061732) for possible PANDUIT Type P and Type S crimp terminal alternatives.

Branch Circuit Protection

Yaskawa recommends installing one of the following types of branch circuit protection to maintain compliance with UL. Semiconductor protective type fuses are preferred. Alternate branch circuit protection devices are also listed. Maximum fuse rating is 175% of drive full load output amps (FLA). This covers any Class CC, J, or T class fuse.

208 V Class Factory-Recommended Fuses

	2011	2017	2024	2031	2046	2059	2075	2088	2114
Bussmann Semiconductor ¹	FWH-40B	FWH-45B	FWH-80B	FWH-125B	FWH-125B	FWH-175B	FWH-200B	FWH-225A	FWH-225A
Alternate Fusing (Class CC, J, or T) ²	Max. Rating (A)	17.5	25	40	50	80	100	125	150
	Max.SCCR (kA)	100	100	100	100	100	100	100	100


480 V Class Factory-Recommended Fuses

	4005	4008	4011	4014	4021	4027	4034	4040	4052	4065	4077	4096	4124
Bussmann Semiconductor ¹	FWH-25A14F	FWH-30A14F	FWH-40B	FWH-45B	FWH-60B	FWH-80B	FWH-100B	FWH-125B	FWH-150B	FWH-200B	FWH-225A	FWH-225A	FWH-225A
Alternate Fusing (Class CC, J, or T) ²	Max. Rating (A)	8	12	17.5	20	35	45	50	70	90	110	125	150
	Max.SCCR (kA)	100	100	100	100	100	100	100	100	100	100	100	100




¹ Recommended EATON/Bussmann Semiconductor fuse model.
² Class CC fuses are time-delay only. Class T fuses are fast-acting (non-time delay only). Class J fuses can be time-delay or non-time delay.




5 Remove the Keypad, Front Cover, Conduit Bracket, and Knock-Outs. Reinstall the Conduit Bracket for non-Cabinet Installations




6 Install the Motor Wiring and Power Wiring



7 Install the Front Cover and Keypad




8 Energize the Drive and Confirm It Is Ready




9 Set the Motor Rated Current (FLA) from the Motor Nameplate in E2-01

3 PHASE INVERTER DUTY AC INDUCTION MOTOR NAMEPLATE EXAMPLE					
MODEL	XX	123AAA123XX-X0		X	FRAME 123AX
POLES	X	ENC XXX	CODE X	DES A	TYPE ABC INS X0
VOLTS	XXX	FL RPM XXXX		FL AMPS XX/XX	
SF 1.0	DUTY CONT	MAX AMB °C XX		TEMP SENSORS	T-STATS
SERIAL		N.L. AMPS XX.X/X.X			
MAX RPM	4200	S.E. BRG. 309	O.S.E. BRG. XXX	ROTOR WK² X.X	
HZ	HP	RPM	TORQUE (LB FT)	VOLTS (HIGH CONN)	AMPS (HIGH CONN)
1	-	0	XX.X	-	XX.X
60	XX	XXXX	XX.X	XXX	XX.X
120	XX	XXXX	XX.X	XXX	XX.X
OHMS PH.	R1: .XXX	R2: .XXX	x1: X.XX	X2: X.XX	X3: XX.X
	P/N XXXXXXX				




10 Set the Drive for HAND Operation and Check the Motor Rotation Direction




Additional Information for Installation and Primary Operation


A How to Set Up the Drive for Monitoring via BACnet MS/TP




B If the Motor Does Not Rotate in the Correct Direction




C Control Circuit Configuration



D Switches and Jumpers on the Control Board




E Connection Diagram and Terminal Functions




Terminal	Type	Signal Level	Default
S1	MFDI 1	Photocoupler 24 V, 6 mA Internal impedance: 4.7 kΩ	Forward run/Stop
S2	MFDI 2		User-defined
S3	MFDI 3		External fault
S4	MFDI 4		Fault reset
S5	MFDI 5		Multi-step speed 1
S6	MFDI 6		Multi-step speed 2
S7	MFDI 7		Jog command
SN	MFDI power 0 V		-
SC	MFDI common	24 V, 150 mA maximum	-
SP	MFDI power + 24 VDC		-
H1	Safe disable input 1	Photocoupler 24 V, 6 mA Internal impedance: 4.7 kΩ	-
H2	Safe disable input 2		-
HC	Safe disable common		-
+V	Frequency setting power supply	10.5 V (20 mA maximum)	-
A1	MFAI 1	0 V ~ 10 V/100% (input impedance 20 kΩ) 4 mA ~ 20 mA/100%	Master frequency reference
A2	MFAI 2	0 mA ~ 20 mA/100% (input impedance 250 Ω)	Combined w/A1
AC	Common	0 V	-
E(G)	Connect shielded cable	-	-
MA	Fault relay out	30 VDC, 10 mA ~ 2 A 250 VAC, 10 mA ~ 2 A Minimum load: 5 V, 10 mA	Fault
MB	Fault relay out		Fault
MC	Common		-
M1	MFDI		During run
M2	MFDI		Zero speed
M3	MFDI	30 VDC, 10 mA ~ 2 A 250 VAC, 10 mA ~ 2 A Minimum load: 5 V, 10 mA	Speed agree 1
M4	MFDI		
M5	MFDI		
M6	MFDI		
FM	MFAO 1	0 V ~ +10 V/0% ~ 100%	Output frequency
AM	MFAO 2	4 mA ~ 20 mA	Output current
AC	Common	0 V	-
+P	External power supply	24 V (150 mA maximum)	-
PS	External 24 V PS input	21.6 VDC ~ 26.4 VDC, 700 mA	-
AC	External 24 V PS ground	0V	-
D+	Communication +	APOGEE FLN, BACnet, MEMOBUS/Modbus, Metasys N2	-
D-	Communication -	RS-485 115.2 kbps maximum	-
AC	Common	0 V	-

F Set Frequency Reference Source



G Set Start/Stop Control Method from External Terminals



```

10:00 am Fwd Parameters
Run Command Selection 1
b1-02
Digital Input
Default : 7
Back Default
    
```

H If You Push the HAND Button but the Motor Does Not Spin

The diagram illustrates the following steps:

- Initial state: 10:00 am Fwd Rdy Home. Freq Reference (KPD) 0.00 Hz, U1-01 Hz 0.00, Output Frequency U1-02 Hz 0.00.
- Pressing the HAND button leads to a warning icon.
- Pressing the Home button (F2) leads to the Language Selection menu.
- Pressing the Home button (F2) again leads to the Parameters menu.
- Pressing the Home button (F2) leads to the Entry Accepted screen.
- Pressing the Home button (F2) leads to the Parameters menu with the HAND Frequency Reference set to 10.00 Hz.
- Pressing the Home button (F2) leads to the Parameters menu with the HAND Frequency Reference set to 10.00 Hz.

I Parameter Groups

A: Initialization	d: Reference Settings	H: Terminal Functions	n: Special Adjustment	T: Auto-Tuning
A1 Initialization	d1 Frequency Reference	H1 Digital Inputs	n1 Hunting Prevention	T0 Tuning Mode Selection
A2 User Parameters	d2 Reference Limits	H2 Digital Outputs	n3 High Slip/Overexcite Braking	T1 Induction/Motor Auto-Tuning
b: Application				
b1 Operation Mode Selection	d3 Jump Frequency	H3 Analog Inputs	n7 EZ Drive	T2 PM Motor Auto-Tuning
b2 DC Injection Braking and Short Circuit Braking	d4 Freq. Ref. Up/Down & Hold	H4 Analog Outputs	n8 PM Motor Control Tuning	T4 EZ Tuning
b3 Speed Search	d6 Field Weakening	H5 Serial Communication	o: Keypad-Related Settings	
b4 Timer Function	d7 Offset Frequency	H7 Virtual Inputs/Outputs	o1 Keypad Display	Y: Application Features
b5 PID Control	E: Motor		o2 Keypad Operation	Y1 Application Basics
b8 Energy Saving	E1 V/f Pattern for Motor 1	L: Protection Functions	o3 Copy Keypad Function	Y2 PID Sleep and Protection
C: Tuning				
C1 Accel & Decel Time	E2 Motor 1 Parameters	L1 Motor Protection	o4 Maintenance Monitors	Y4 Application Advanced
C2 S-Curve Characteristics	E3 V/f Pattern for Motor 2	L2 Power Loss Ride Through	o5 Log Function	Y9 Network Multiplex Options
C3 Slip Compensation	E4 Motor 2 Parameters	L3 Stall Prevention	q: DriveWorksEZ Parameters	
C4 Torque Compensation	E5 PM Motor Settings	L4 Speed Detection	r: DriveWorksEZ Connections	
C5 Auto Speed Regulator (CSR)	E9 Motor Setting	L5 Fault Restart	S: Special Applications	
C6 Carrier Frequency	F: Options		S1 Dynamic Noise Control	YF PI Auxiliary Control
	F6 Communication Option	L6 Torque Detection	S2 Sequence Run Timers	
	F7 Ethernet Options	L7 Torque Limit	S3 PI2 Control	
		L8 Drive Protection	S5 HAND/OFF/AUTO Operation	
		L9 Drive Protection 2	S6 Protection	

Frequently Used Parameters

Parameter Number Name	Default Description	Parameter Number Name	Default Description	Parameter Number Name	Default Description
A1-06 Application Preset	0 No preset	b5-03 Integral Time (I)	0.5 s	d2-02 Frequency Reference Lower Limit	0.0%
b1-01 Frequency Reference Selection 1	1 Analog Input	b5-05 Derivative Time (D)	0.00 s	E1-01 Input AC Supply Voltage	-
b1-02 Run Command Selection 1	7 AUTO Command + Term Run	C1-01 Acceleration Time 1	30.0 s	E2-01 Motor Rated Current (FLA)	-
b1-03 Stopping Method Selection	1 Coast to Stop	C1-02 Deceleration Time 1	30.0 s	H3-09 Terminal A2 Signal Level Select	2 4 to 20 mA
b5-01 PID Mode Setting	0 Disabled	d2-01 Frequency Reference Upper Limit	100.0%	H3-10 Terminal A2 Function Selection	0 Frequency Reference
b5-02 Proportional Gain (P)	2.00				

J Troubleshooting Resources for Drive Faults and Alarms

Resource	Choose This When:	URL	QR Code
Installation & Primary Operation	You have access to the paper copy of the manual that was packaged with the drive. This manual lists all drive faults and alarms, and offers a selection of causes and solutions.	https://www.yaskawa.com/toepc71061732	 PDF download
DriveWizard Mobile App	You want to use your smartphone or tablet and use the embedded help to look up the full complement of causes and solutions to all drive faults and alarms.	https://www.yaskawa.com/dwm	 App download
Maintenance & Troubleshooting Manual	You want to download a PDF of the manual to your smartphone or tablet. This manual lists the full complement of causes and solutions to all drive faults and alarms and also includes detailed information about drive maintenance, wiring, and programming.	https://www.yaskawa.com/toepyaihv6001	 PDF download

K Additional Resources

Download on the **App Store** or GET IT ON **Google Play**

Mobile App

Product Manuals

•PDFs
•Online HTML5-Searchable
•Manuals App
<https://www.yaskawa.com/dwm>
<https://www.yaskawa.com/hv600manuals>

L Customer Feedback

Comments or questions about this document? Fill out our online form:

OR
Email us: technical_documentation@yaskawa.com
Call us: 1-800-YASKAWA (927-5292)
www.yaskawa.com/DRV-F-0006

Please consider following us on social media:

www.youtube.com/yaskawayea

www.linkedin.com/company/18822

www.twitter.com/yaskawa

Headquarters Address:
YASKAWA AMERICA, INC.
2121 Norman Drive South
Waukegan, IL 60085
USA
© 2020 YASKAWA Electric Corporation
MANUAL NO. TOEP C710617 74B <1>-0
Published in Japan April 2020