YASKAWA

SigmaLogic7 Compact

Sigma-7 SERVOPACK Option



Motion Sequencing with Add On Instructions (AOIs) for Rockwell ControlLogix and CompactLogix PLCs

SigmaLogic7 Compact makes it possible to add the superior performance and unmatched reliability of a Yaskawa servo system to your machine, without leaving the familiar format of an existing programmable logic controller.

Users can now utilize Yaskawa written, Yaskawa tested Add On Instructions in RSLogix5000 software, with a ControlLogix or CompactLogix PLC. No other Yaskawa programming software is required. This opens up a range of automation improvements:

- Perform functions including point-to-point and blended space moves, as well as jogging and homing
- Use direct commands or a 200-point configurable sequence table
- Utilize the extra 7 inputs and 3 outputs on the SigmaLogic7 Compact servo system in an indexing sequence table, or in your PLC application
- The LogicWorks[™] v2 software utility may be used to download sequence and configuration data
- Contains all the features of a Sigma-7 servo system:
 - Tuningless mode automatically adjusts for loadto-rotor inertia mismatches up to 30:1, allowing for the use of smaller motors and reduced gearing
 - Vibration suppression reduces noise during operation, improving tracking and settling time to yield machined parts with very smooth edges
 - 24-bit absolute encoders
 - 50W to 15kW. 100 or 230 VAC input
 - UL/CE/RoHS
 - Integrated safety (Safe Torque Off)



EtherNet/IP

Yaskawa-written, Yaskawa tested AOIs

- Configurable sequence table
- Extension of Sigma-7 servo family

Sequence Table with



- Software utility to create individual move profiles and sequencing for the application
- Upload/download sequence table and configuration data to/ from LogicWorks[™]
- Embedded monitoring and test functions

Add On Instructions (AOI)

- Yaskawa AOIs were created for full compatibility with all CompactLogix and ControlLogix PLCs using RSLogix5000 software v17 and above
- AOIs are named to be familiar to Rockwell users
- Right-click instruction help is available for all instructions when in the PLC programming environment
- Sample program in RSLogix5000 is available

MCFG_YaskawaMotion Axis ConfigurationMSO_YaskawaMotion Axis Servo OnMSF_YaskawaMotion Axis Servo OffMAS_YaskawaMotion Axis StopMAFR_YaskawaMotion Axis Fault ResetMAM_YaskawaMotion Axis MoveMAJ_YaskawaMotion Axis JogMAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis HomingMAH_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MSO_YaskawaMotion Axis Servo OnMSF_YaskawaMotion Axis Servo OffMAS_YaskawaMotion Axis StopMAFR_YaskawaMotion Axis Fault ResetMAM_YaskawaMotion Axis MoveMAJ_YaskawaMotion Axis JogMAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis Home Set PositionMAB_YaskawaMotion Axis Index Step EditMSQE_YaskawaMotion Axis Index Step Edit
MSF_YaskawaMotion Axis Servo OffMAS_YaskawaMotion Axis StopMAFR_YaskawaMotion Axis Fault ResetMAM_YaskawaMotion Axis MoveMAJ_YaskawaMotion Axis JogMAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis HomingMAB_YaskawaMotion Axis Index StepMSQR_YaskawaMotion Axis Index Step Edit
MAS_YaskawaMotion Axis StopMAFR_YaskawaMotion Axis Fault ResetMAM_YaskawaMotion Axis MoveMAJ_YaskawaMotion Axis JogMAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis HomingMAB_YaskawaMotion Axis "Blend" MoveMSQR_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MAFR_YaskawaMotion Axis Fault ResetMAM_YaskawaMotion Axis MoveMAJ_YaskawaMotion Axis JogMAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis HomingMAB_YaskawaMotion Axis "Blend" MoveMSQR_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MAM_YaskawaMotion Axis MoveMAJ_YaskawaMotion Axis JogMAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis HomingMAB_YaskawaMotion Axis "Blend" MoveMSQR_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MAJ_YaskawaMotion Axis JogMAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis HomingMAB_YaskawaMotion Axis "Blend" MoveMSQR_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MAHSP_YaskawaMotion Axis Home Set PositionMAH_YaskawaMotion Axis HomingMAB_YaskawaMotion Axis "Blend" MoveMSQR_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MAH_YaskawaMotion Axis HomingMAB_YaskawaMotion Axis "Blend" MoveMSQR_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MAB_YaskawaMotion Axis "Blend" MoveMSQR_YaskawaMotion Axis Index Run SequencerMSQE_YaskawaMotion Axis Index Step Edit
MSQR_Yaskawa Motion Axis Index Run Sequencer MSQE_Yaskawa Motion Axis Index Step Edit
MSQE_Yaskawa Motion Axis Index Step Edit
MHSI_Yaskawa Motion Axis High Speed Index
MTRQ_Yaskawa Motion Axis Torque Control
MCLK_Yaskawa Motion Axis Set Clock
MPLS_Yaskawa Motion Axis Programmable Limit Switch
MRSE_Yaskawa Motion Report Servo Error

Home Types

Set Position Directly Home in Positive Direction to Hard Stop Home in Negative Direction to Hard Stop Home in Positive Direction to Limit w/o C-Pulse Home in Negative Direction to Limit w/C-Pulse Home in Negative Direction to Limit w/C-Pulse Home in Negative Direction to Input w/o C-Pulse Home in Negative Direction to Input w/o C-Pulse Home in Negative Direction to Input w/o C-Pulse Home in Negative Direction to Input w/C-Pulse Home in Negative Direction to Input w/C-Pulse Home in Negative Direction to Input w/C-Pulse Home in Negative Direction to Input w/C-Pulse

Move Types Absolute Move Absolute Move with Registration Relative Move Relative Move with Registration Blended Move Jog Jog with Registration Torque Move High Speed Index Rotary Absolute Move with Shortest Path

Model Number Designation



1st+2nd+3rd digits Maximum Applicable Motor Capacity										4th digit Voltage			8th+9th+10th digits Hardware Options Specification		
Voltage	Code	Spec.	Voltage	Code	Spec.	Voltage	Code	Spec.		Code	Specification	Code	Specification	Applicable Models	
Single- phase, 100 VAC	R70	0.05 kW	Three- phase, 200 VAC	R70*1	0.05 kW	Three- phase, 400 VAC	1R9	500 W		A	200 VAC	Oode	opecilication		
	R90	0.1 kW		R90*1	0.1 kW		3R5	1.0 kW		F	100 VAC	000	Without options	All models	
	2R1	0.2 kW		1R6*1	0.2 kW		5R4	1.5 kW		D	400 VAC				
	2R8	0.4 kW		2R8*1	0.4 kW		8R4	2.0 kW				11th+	12th+13th digits	T/EX Specification	
				3R8	0.5 kW		120	3.0 kW		_					
				5R5*1	0.75 kW		170	5.0 kW	5th+6t Code Q0	5th+6t	th digits Interface	Code	Specificati	on	
				7R6	1.0 kW		210	6.0 kW		Specification	F51	Application function	n for SigmaLogic7		
				120	1.5 kW		260	7.5 kW		SigmaLogic7 Compact					
				180	2.0 kW		280	11 kW							
				200	3.0 kW		370	15 kW							
				330	5.0 kW	7th digit Design Revision Order									
				470	6.0 kW	A: Global design revision									
				550	7.5 kW	B: 400 V global design revision *1: These models can be used with either a single-phase or three-phase power supply input									
				590	11 kW										
				780	15 kW										

1-800-YASKAWA Email: info@yaskawa.com Document FL.SL7C.01 © 2019 Yaskawa America, Inc.

